

# KJC-CHARGING PUMP LIST

## <KOMATSU>



### DESCRIPTION

**KOMATSU  
PC200-3  
(704-24-28200)  
(704-24-28203)**



### DESCRIPTION

**KOMATSU  
PC200-5  
(704-24-28230)**



### DESCRIPTION

**KOMATSU  
PC100-5  
(704-24-26401)**



### DESCRIPTION

**KOMATSU  
PC200-6  
(704-24-24420)**



### DESCRIPTION

**KOMATSU  
PC300-6  
(704-24-26430)**



### DESCRIPTION

**KOMATSU  
CGP5-33  
(07430-72203)**



### DESCRIPTION

**KOMATSU  
CGP5-42  
(07432-71203)**



### DESCRIPTION

**KOMATSU  
SAL3-080  
(705-11-38010)**



### DESCRIPTION

**KOMATSU  
KOM2770  
(07959-3000)**



### DESCRIPTION

**KOMATSU  
KOM1969  
(07959-2000)**

## CONTACT

Website : [www.kjchdraulic.com](http://www.kjchdraulic.com)

Phone : +82 31 409 0746

FAX : +82 31 409 5290

Email : [kjcsteve@gmail.com](mailto:kjcsteve@gmail.com)

Address : 2F, 53 Idonggongwon-ro, Sangrok-gu,,  
Ansan-si, Gyeonggi-do, 15489, Korea.

# KJC-CHARGING PUMP LIST

## <KOMATSU>



### DESCRIPTION

**KOMATSU  
SAL3-56  
(705-11-35010)**



### DESCRIPTION

**KOMATSU  
SAL3-63  
(705-11-36010)**



### DESCRIPTION

**KOMATSU  
SAR3-080FS  
(705-12-38211)**



### DESCRIPTION

**KOMATSU  
SAL3-100FS  
(705-21-40020)**



### DESCRIPTION

**KOMATSU  
SAL3-80+100  
(705-51-30360)**



### DESCRIPTION

**KOMATSU  
SAL3-63+32  
(705-51-32080)**



### DESCRIPTION

**KOMATSU  
SAR3-80+56  
(705-52-30220)**



### DESCRIPTION

**KOMATSU  
SAR3-71+50  
(705-52-30280)**



### DESCRIPTION

**KOMATSU  
SAR3-56+45  
(705-52-30360)**



### DESCRIPTION

**KOMATSU  
SAR3-100+(1)28  
(705-52-30390)**

## CONTACT

Website : [www.kjchdraulic.com](http://www.kjchdraulic.com)

Phone : +82 31 409 0746

FAX : +82 31 409 5290

Email : [kjcsteve@gmail.com](mailto:kjcsteve@gmail.com)

Address : 2F, 53 Idonggongwon-ro, Sangrok-gu,,  
Ansan-si, Gyeonggi-do, 15489, Korea.

# KJC-CHARGING PUMP LIST

## <KOMATSU>



### DESCRIPTION

**KOMATSU  
SAR3-100+100  
(705-52-32270)**



### DESCRIPTION

**KOMATSU  
SAL3-100+50+36+(1)25  
(705-55-34181)**




### DESCRIPTION

**KOMATSU  
SAR3-80+63+50  
(705-56-34040)**



### DESCRIPTION

**KOMATSU  
SAR3-  
80+63+50+(1)12  
(705-56-34100)**



### DESCRIPTION

**KOMATSU  
SAL2-40+20  
(705-51-20430)  
(705-51-20070)**



### DESCRIPTION

**KOMATSU  
SAR2-50+20  
(705-52-20240)**



### DESCRIPTION

**KOMATSU  
SAL2-50+20  
(705-51-20480)**



### DESCRIPTION

**KOMATSU  
SAL2-40+40  
(705-51-20640)**



### DESCRIPTION

**KOMATSU  
SAR2-50+50  
(705-52-20090)**



### DESCRIPTION

**KOMATSU  
NOZZLE  
WASHER-C1100**

## CONTACT

Website : [www.kjchdraulic.com](http://www.kjchdraulic.com)

Phone : +82 31 409 0746

FAX : +82 31 409 5290

Email : [kjcsteve@gmail.com](mailto:kjcsteve@gmail.com)

Address : 2F, 53 Idonggongwon-ro, Sangrok-gu,,  
Ansan-si, Gyeonggi-do, 15489, Korea.

# KJC-CHARGING PUMP LIST

## <KOMATSU>



### DESCRIPTION

**KOMATSU  
O-RING-42110**




### DESCRIPTION

**KOMATSU  
O-RING-42570**



### DESCRIPTION

**KOMATSU  
GCP-40  
(14X-49-11600)**



### DESCRIPTION

**KOMATSU  
KO-3060**



### DESCRIPTION

**KOMATSU  
OP-12  
(6204-51-1100)  
(6204-51-1610)**



### DESCRIPTION

**KOMATSU  
OP-16  
(6206-51-1100)  
(6206-51-1200)**



### DESCRIPTION

**KOMATSU  
OP-21  
(6207-51-1100)  
(6207-51-1200)**



### DESCRIPTION

**KOMATSU  
OP-32-21T  
(6209-51-1100)  
(6209-51-1201)**

## CONTACT

Website : [www.kjchdraulic.com](http://www.kjchdraulic.com)

Phone : +82 31 409 0746

FAX : +82 31 409 5290

Email : [kjcsteve@gmail.com](mailto:kjcsteve@gmail.com)

Address : 2F, 53 Idonggongwon-ro, Sangrok-gu,,  
Ansan-si, Gyeonggi-do, 15489, Korea.